# $\Omega$ megaPost

# IMPACT recovery SYSTEMS



# NTPEP TESTED 200+ IMPACTS AT 70 MPH

## **BEST HIGH SPEED MANAGED LANE SOLUTION**

- No fasteners to corrode
- Simple installation and replacement
  - Durable, high speed performance
    - Heavy load crash tolerant
- Type V Super high intensity sheeting
- Ultraviolet light, ozone, and hydrocarbon resistant
  - 100% made in the USA
    - MUTCD compliant
  - Category 1 Self Certified Device
    - Patent Pending











# **ΩmegaPost**

### PRODUCT SPECIFICATIONS



OmegaPost is a Category 1 small and light weight device with no attachements. Products such as these have been in common use for many years and are known to be crash worthy by testing of similar devices and years of demonstrable safe performance.


### **RECOMMENDED USES**

Managed Lanes, HOV Lanes, Bike Lanes, Urban Restrictions, High Speed Traffic, Corrosive Environments

### **POST OPTIONS**

Open top, Cap, or Long Squeeze

### SHEETING COLORS



### **POST COLOR OPTIONS**



### **BASE OPTIONS**

ΩmegaPost<sup>™</sup> can only be used with the Quarter Turn Surface Mount base in black (standard) or whilte/yellow



### **BASE REFLECTORS**



ΩmegaPost Delineator	Height	Post Diameter	Post Colors	Optional Sheetin	R. Sheetin Type	R. Sheetin Colors	Base Type
ΩmegaPost 2" Open Top	28" 36" 42"	2.375"	Yellow, Orange <i>or</i> White	Two 3" bands of reflective sheeting	Type V High Intensity	White, orange, yellow, red, green <i>or</i> blue	Suraface Mount Quarter Turn Base
ΩmegaPost 2" Long Squeeze 14"					Abrasion Resistant Sheeting		

<sup>\*</sup>Base and base mounting hardware is sold separately. Post spring type must be specified at time of order. \*\* Protective Bollard height is based on post height. \*Open Top post is left with a smooth cut, open top

### TWO METHODS OF INSTALLATION:





1. Insert the threaded post into base with holes aligned 90° to keeper pin slot.



2. Push down to insert the post and rotate clockwise until fully seated.



3. Install L-shaped keeper pin through base and into post hole such that the pin lies flat in the retention slot on the top of the base.



